

A. GENERAL INSTRUCTIONS

1. Insert the cleaning tip into the adapter



PCT-FAC-500-LC is designed for the depth of LC & MU adapters

PCT-FAC-500-SC is designed for the depth of SC, FC & ST adapters

2. Rotate the cleaner 2 to 3 times inside the ferrule to clean the adapter
3. While holding the cleaner inside the ferrule, advance the cleaning fabric by rotating the dial 1 or 2 clicks clockwise
3. Replace the cap



When not in use, keep capped to prevent contamination



B. ATTENTION

1. Do not turn the dial counter-clockwise and do not turn it more than two (2) clicks
 - a. The dial should be turned just 1 to 2 clicks clockwise to advance the cleaning fabric
2. If the cleaning fabric gets caught in the zirconia sleeve of the adapter, do not turn the dial.
 - a. Gently remove the cleaning tip from the adapter, advance the dial to expose fresh cleaning fabric, and insert again
3. Cleaning performance may be affected by contamination and environmental factors.
4. This unit is disposable so please dispose of the unit properly when the cleaning fiber is completely used up
5. **For better cleaning**, rotate the cleaner 2 to 3 times before advancing the cleaning fabric with the dial
 - a. The ferrule cleaning will be more effective by performing both steps (rotating the cleaner and advancing the cleaning fabric)

